





































| Circuit Analysis with Devices: THOMSON Theory and Practice | | | | |
|---|------------------|--------|--------|----|
| Prefixes | | | | |
| Metric Prefixes are used for convenience | | | | |
| 1 1 1 1 | Power of 10 | Prefix | Symbol | |
| | 10 ¹² | tera | Т | |
| | 10^{9} | giga | G | |
| | 10^{6} | mega | Μ | |
| | 10^{3} | kilo | k | |
| | 10^{-3} | milli | m | |
| | 10^{-6} | micro | μ | |
| | 10^{-9} | nano | n | |
| | 10^{-12} | pico | р | |
| | | | | 20 |
| Robbins and Miller Copyright © 2007 Thomson Delmar Learning | | | | |

















This document was created with Win2PDF available at http://www.daneprairie.com. The unregistered version of Win2PDF is for evaluation or non-commercial use only.